ATTACHMENT 1
RFQ NUMBER 19H08020Q0019

MAKE	CHEVROLET		FORD		JEEP	NISSAN	TOYOTA																			
MODELS	SUBURBAN 2020	EQUINOX 2020	EXPLORER 2010-2020	RANGER 2017	GRAND CHEROKEE 2006	PICK UP 2013-2020	FORTUNER 2012	HIACE 2007	HIACE 2012	HILUX D/C 2004	HILUX D/C 2007	HILUX D/C 2010	HILUX D/C 2014	HILUX D/C 2017	HILUX D/C 2018	HILUX D/C 2020	LAND CRUISER 2002	LAND CRUISER 2006	LAND CRUISER 2007	LAND CRUISER 2008	LAND CRUISER 2009	LAND CRUISER 2010	LAND CRUISER 2014	LAND CRUISER PRADO 2008	LAND CRUISER PRADO 2009	URBAN CRUISER 2012
Every 5,000 Kilometers																										
Change Oil and Filter 10w 50 Synthetic Multi grade For Gasoline Engine																										
Change Oil and Filter 10w 40 Synthetic Multi grade For Diesel Engine																										
Check all fluids and replace/top off as required (brake, steering, etc.)																										
Check Tire Pressure and Tire Condition																										
Check all Belts and Hoses and replace as required																										
Lubricate Chassis																										
Inspect Brakes and adjust/replace as required																										
Clean Battery Connections																										
Rinse off Air Conditioner Condenser (de-install and wash)																										
Add Fuel Injector Cleaner to fuel																										
Check and Replace Washer Fluid Level																										
Check Wiper Blades and replace as required																										
Every 16,000 Kilometers (Tune-Up & Diagnostic Check):																										
Change Oil and Filter 10w 50 Synthetic Multi grade For Gasoline Engine																										
Change Oil and Filter 10w 40 Synthetic Multi grade For Diesel Engine																										
Replace Filters (air, fuel, PCV)																										
Lubricate Chassis																										
Check and clean Brakes and grease Wheel Bearings																										
Check and adjust valves if rocker-type arm																										
Check and replace all belts including timing belt																										
Check temperature and replace engine thermostat																										
Replace plugs, points, cap, rotor, and all necessary tune-up and emission items if applicable																										
Inspect cooling system hoses and fluid for cleanliness, Replace if needed																										
Adjust wheel Alignment as needed																										
Check and recharge Air Conditioning system																										
Every 32,000 Kilometers or 2 Years (Same as 16,000 KM or Annual plus the following):																										
Bleed brakes to replace brake fluid																										
Replace automatic transmission oil if using petroleum. Change filter and clean screen and magnets																										
Every 48,000 Kilometers or 3 Years (Same as 16,000 KM or Annual plus the following):																										
Inspect U-Joints and grease-CHASSIS																										
Replace Spark Plugs if applicable (some are designed to last up to 160,000 KM, so check to see what kind the vehicle has)																										
Inspect and replace shocks for leaks and perform bounce test																										
Clean and Inspect Throttle body																										
Check and replace Steering pitman Arm, Drag Link and Idler Arm																										
Check and replace tie rod ends																										
Check and replace Transmission Mounts																										
Check Slip Joint and grease																										
Every 80,000 Kilometers or 5 Years (Same as 16,000 KM or Annual plus the following):																										
Replace oil in manual transmissions																										
Replace oil in automatic transmission using synthetic																										
Replace oil in differentials and transfer case																										
Inspect Front Alignment and Adjust if needed																										
Every 96,000 Kilometers or 5 Years (Same as 16,000 KM or Annual plus the following):																										
Replace rubber timing belt on camshafts																										